



ABOUT MONSIEUR TRICOT LAMPS

The spheres of the Monsieur Tricot lamps are made of PMMA thermoplastic which has a high scratch and weather resistance. The knitted or crocheted covers are made of polypropylene which has good strength, as well as a high resistance to water, frost, heat, mould and mildew. The covers can be removed to clean the sphere and the cover.

GENERAL GUIDELINES

- Cleaning should be done preferably during cloudy weather or in the shade. Make sure the spheres are cooled down before you start.
- Beware of sensitive flooring and wear protective gloves.
- Do not use any abrasive sponges, steel brushes, wonder sponge or any abrasive/caustic cleaner.
- Do not use a high pressure cleaner nor a steamer.
- Make sure the weave is clean and completely dry before you apply protective products.
- Storage during winter time or long absence: before storing, we recommend good cleaning and protection of your lamps. Store only in a dry, well-ventilated and unheated room and never use non-breathable plastic covers.

RECOMMENDED PRODUCTS

1. Synthetics Super Cleaner
2. Textile Protector



CLEANING

- Turn the sphere counterclockwise until it comes free from the base.
- Loosen the elastic strap of the removable cover and pull it over the rim of the sphere.
- Pull the cover off the sphere.
- Remove dust/dirt from the sphere with a soft brush. Spray **Synthetics Super Cleaner (1)** onto the sphere and let it soak for a minute. Rinse abundantly and then dry with a microfiber cloth.
- The cover can be washed at 40°C with a pH-neutral washing agent.
- If the weave is heavily soiled, we advise using Synthetics Super Cleaner.
- Mist the weave with some clean tap water, for example with a plant sprayer.
- Spray the Synthetics Super Cleaner onto the weave and let the cleaning agent soak for 1-2 minutes. Make sure the weave stays moist to keep the cleaner active.
- Gently brush the weave with a soft hand brush and let the cleaner soak for another minute.
- Finally rinse the cover well with clean tap water and remove excess water with a clean microfiber cloth. Let the cover dry in the open air.
- Pull the cover back over the sphere and tighten the elastic. Twist it and pull it over the rim of the sphere.
- Place the sphere over the base. Turn the sphere clockwise until it is secured.

PROTECTING

- Treating the covers with **Textile Protector (2)** regularly will make cleaning easier. Furthermore, the weave will dry quicker. Attention, do not spray Textile Protector onto the sphere as this may affect the transparency and therefore the brightness of the light.
- Shake the aerosol well and apply onto a clean microfiber cloth
- Gently wipe the product onto the weave.
- Let the weave dry in the open air.

ATTENTION

- Do not tumble dry the cover.
- Extend the Monsieur Lebonnet cover well before drying.
- Do not use a scouring pad to clean the sphere, this may cause scratches.



1. Monsieur Tricot hanging lamps
2. Monsieur Tricot standing lamps