






ASSEMBLY INSTRUCTION

06040-XX-XX FORUM Lounger Textiline Back

<p>General Conditions :</p> <p>1. Put the lounger upside down on some cloth or foam to avoid damage during this exchange.</p>	<p>1. untight the bolts that hold the movable headrest.</p> 	<p>2. untight the bolts that hold both reinforcement strips</p> 	<p>3. untight the moving U-shape that is used to put the lounger headrest into position.</p> 	<p>4. Use a clamp to put pressure on the welded reinforcement strip so that the textiline is no longer tight.</p> 
<p>Remove now the textiline from the headrest and put the new one into position.</p>	<p>5. Use the clamp to press the frame open before putting the reinforcement strips into position.</p> 			<p>Reverse the disassembly process to assemble the backrest back into position on the lounger. To exchange a textiline on the backrest should take about 30 minutes work with 2 persons.</p>